



Spare parts for:

COFFEE GRINDERS

ROSSI


Important:

- this catalogue is automatically generated, therefore the sequence of the items might not be always shown at best
- updates will be issued in case of additions and/or amendments





GRINDER ASSEMBLY RR45




RO0101

Positions without LF code no.: upon request



Position	LF code no.	Description
1	1252581	COFFEE HOPPER LID ø 180 mm
6	1252584	COFFEE HOPPER CLOSING SHEET
8	1252580	ADJUSTMENT RING NUT
9	1324931	INLET CONTROL PIN
10	1250931	CONTROL PIN SPRING
11	1186921	GASKET FOR COFFEE OUTLET OPENING
13	1252582	FILTER HOLDER FORK
14	1528631	CROSS HEAD SCREW M4x8 UNI 7687
15	1390003	RELAY BOARD
17	3068019	CAPACITOR µF 12,5 450V 50/60Hz
21	1252585	COFFEE GRINDER/DOSER BASE
22	1252586	COFFEE COLLECTION TRAY
29	3319019	RED BIPOLAR SWITCH 16A 250V
29	3319934	ORANGE BIPOLAR SWITCH 16A 250V
30	1251916	GRINDING BURRS UPPER HOLDER
31	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
34	1251917	GRINDING BURRS LOWER HOLDER
35	1252378	THREADED RING NUT 15MCx1
36	1250130	SEEGER ø 35 mm
37	1252377	BEARING LOCKING WASHER
38	1252376	COMPENSATION RING
47	1313908	FOOT FOR COFFEE GRINDER/DOSER
49	1080917	COMPLETE COFFEE HOPPER
50	1009005	ADHESIVE PLATE
51	1250933	SHAPED SPRING
52	1324933	SPRING SHAFT SEAT
54	1343031	UPPER STAR
55	1252587	CLOSING SECTOR RH
56	1343032	MIDDLE STAR
57	1250932	COFFEE TAMPER SPRING
59	1343033	LOWER STAR
60	1252590	PIN GUIDE
63	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
64	1385539	COFFEE TAMPER ASSEMBLY ø 55 mm
65	1250935	CONTACTOR SPRING RH
65	1250936	CONTACTOR SPRING LH
67	1250937	SHAPED PIN SPRING
69	1324934	PIN ø 4x16 mm
70	1250934	PIN SPRING
72	1252591	PAWL FOR COFFEE GRINDER/DOSER
76	1439823	DOSER BOTTOM LID
78	1050001	SPIRAL CABLE
79	1390004	MAGNETIC MICROSWITCH ø 7x35 mm
80	1439822	DOSER LID
81	3240123	MICROSWITCH 16A 250V
82	1120201	SILICONE MEMBRANE
83	1240932	MICROSWITCH PUSH-BUTTON
84	1252046	MICROSWITCH BOX
86	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
87	1252047	CHROME-PLATED DISPENSER RING
88	1252589	DOSER CYLINDER
89	1241916	CONTROL KNOB
91	1528627	S/STEEL SCREW T.S.P.C.E.I. M8x20 UNI 5933
93	1252588	COUNTER FOR COFFEE GRINDER
94	1250058	TRIGGERING SPRING
95	1225911	DOSER LEVER RH
95	1225912	LH DOSER LEVER WITH PIN
96	1324921	DOSER PIN
100	1385001	MOBILE TAMPER COMPLETE
101	1241911	COFFEE TAMPER HANDLE
102	1324932	PIN FOR MANUAL COFFEE TAMPER
103	1250932	COFFEE TAMPER SPRING
104	1385536	COFFEE TAMPER SUPPORT
105	1385537	COFFEE TAMPER
107	1385538	COFFEE TAMPER

GRINDER ASSEMBLY RR55-RR65



RO0201

Positions without LF code no.: upon request




Position	LF code no.	Description
1	1390004	MAGNETIC MICROSWITCH $\varnothing$ 7x35 mm
2	1009005	ADHESIVE PLATE
3	1439822	DOSER LID
5	3240123	MICROSWITCH 16A 250V
6	1252046	MICROSWITCH BOX
8	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
9	1252047	CHROME-PLATED DISPENSER RING
10	1252589	DOSER CYLINDER
11	1250933	SHAPED SPRING
12	1324933	SPRING SHAFT SEAT
14	1343031	UPPER STAR
15	1252587	CLOSING SECTOR RH
16	1343032	MIDDLE STAR
17	1250932	COFFEE TAMPER SPRING
18	1343033	LOWER STAR
19	1252590	PIN GUIDE
21	1385539	COFFEE TAMPER ASSEMBLY $\varnothing$ 55 mm
23	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
24	1250935	CONTACTOR SPRING RH
26	1250937	SHAPED PIN SPRING
28	1324934	PIN $\varnothing$ 4x16 mm
29	1250934	PIN SPRING
36	1050001	SPIRAL CABLE
37	1120201	SILICONE MEMBRANE
38	1240932	MICROSWITCH PUSH-BUTTON
39	1241916	CONTROL KNOB
42	1528627	S/STEEL SCREW T.S.P.C.E.I. M8x20 UNI 5933
44	1252588	COUNTER FOR COFFEE GRINDER
45	1252591	PAWL FOR COFFEE GRINDER/DOSER
47	1225911	DOSER LEVER RH
47	1225912	LH DOSER LEVER WITH PIN
48	1324921	DOSER PIN
52	1080501	STANDARD COFFEE HOPPER 2 Kg
53	1252584	COFFEE HOPPER CLOSING SHEET
59	1080917	COMPLETE COFFEE HOPPER
60	1252581	COFFEE HOPPER LID $\varnothing$ 180 mm
61	1252048	NONTOXIC CLAMP
63	1324935	RR-45S/CC-45 HOPPER ADAPTER PIN
64	1250931	CONTROL PIN SPRING
65	1252583	ADJUSTMENT RING NUT
70	1186497	GASKET FOR COFFEE OUTLET OPENING
71	1252044	FILTER HOLDER FORK
72	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
74	1251916	GRINDING BURRS UPPER HOLDER
75	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
77	1251917	GRINDING BURRS LOWER HOLDER
78	1528631	CROSS HEAD SCREW M4x8 UNI 7687
86	3068019	CAPACITOR μ F 12,5 450V 50/60Hz
96	1390003	RELAY BOARD
103	3319019	RED BIPOLAR SWITCH 16A 250V
103	3319934	ORANGE BIPOLAR SWITCH 16A 250V
104	1313908	FOOT FOR COFFEE GRINDER/DOSER



COFFEE GRINDER RR550D ON DEMAND

RR550D



RO0211





Position	LF code no.	Description
1	1252581	COFFEE HOPPER LID ø 180 mm
2	1080067	COFFEE HOPPER
3	1252584	COFFEE HOPPER CLOSING SHEET
5	1252580	ADJUSTMENT RING NUT
14	3319019	RED BIPOLAR SWITCH 16A 250V
14	3319934	ORANGE BIPOLAR SWITCH 16A 250V
15	1251916	GRINDING BURRS UPPER HOLDER
16	1251094	GRINDING BURRS PAIR ROSSI LH
17	1528631	CROSS HEAD SCREW M4x8 UNI 7687
20	1251917	GRINDING BURRS LOWER HOLDER
21	1252378	THREADED RING NUT 15MCx1
22	1250130	SEEGER ø 35 mm
23	1252377	BEARING LOCKING WASHER
24	1252376	COMPENSATION RING
25	3063005	BEARING 6202 2RS
36	1313908	FOOT FOR COFFEE GRINDER/DOSER
44	1324931	INLET CONTROL PIN
45	1250931	CONTROL PIN SPRING
50	1385538	COFFEE TAMPER
61	3068024	CAPACITOR µF 16 450V 50/60Hz
66	1090011	DOSER LID ø 125 mm
68	1240045	LID FOR MICROSWITCH CASE
69	1240048	MICROSWITCH FLAP
70	1240046	MICROSWITCH SUPPORT



GRINDER ASSEMBLY CC45

CC45



RO0301


Positions without LF code no.: upon request



Position	LF code no.	Description
1	1080501	STANDARD COFFEE HOPPER 2 Kg
2	1252584	COFFEE HOPPER CLOSING SHEET
8	1324935	RR-45S/CC-45 HOPPER ADAPTER PIN
9	1250931	CONTROL PIN SPRING
11	1252583	ADJUSTMENT RING NUT
15	3319019	RED BIPOLAR SWITCH 16A 250V
15	3319934	ORANGE BIPOLAR SWITCH 16A 250V
22	1252050	FILTER HOLDER FORK
24	1251916	GRINDING BURRS UPPER HOLDER
25	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
28	1528631	CROSS HEAD SCREW M4x8 UNI 7687
29	1251917	GRINDING BURRS LOWER HOLDER
46	1313908	FOOT FOR COFFEE GRINDER/DOSER
47	1252045	COFFEE COLLECTING TRAY
48	3068019	CAPACITOR μ F 12,5 450V 50/60Hz
50	1390003	RELAY BOARD
51	1390004	MAGNETIC MICROSWITCH $\varnothing$ 7x35 mm
52	1009005	ADHESIVE PLATE
53	1439822	DOSER LID
54	3240123	MICROSWITCH 16A 250V
56	1252046	MICROSWITCH BOX
57	1050001	SPIRAL CABLE
58	1120201	SILICONE MEMBRANE
59	1240932	MICROSWITCH PUSH-BUTTON
60	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
61	1252047	CHROME-PLATED DISPENSER RING
62	1252589	DOSER CYLINDER
63	1250933	SHAPED SPRING
64	1324933	SPRING SHAFT SEAT
66	1343031	UPPER STAR
67	1252587	CLOSING SECTOR RH
68	1343032	MIDDLE STAR
69	1250932	COFFEE TAMPER SPRING
70	1343033	LOWER STAR
71	1241916	CONTROL KNOB
74	1528627	S/STEEL SCREW T.S.P.C.E.I. M8x20 UNI 5933
76	1252590	PIN GUIDE
78	1385539	COFFEE TAMPER ASSEMBLY $\varnothing$ 55 mm
80	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
81	1250935	CONTACTOR SPRING RH
83	1250937	SHAPED PIN SPRING
85	1324934	PIN $\varnothing$ 4x16 mm
86	1250934	PIN SPRING
93	1252588	COUNTER FOR COFFEE GRINDER
94	1252591	PAWL FOR COFFEE GRINDER/DOSER
96	1225911	DOSER LEVER RH
96	1225912	LH DOSER LEVER WITH PIN
97	1324921	DOSER PIN



GRINDER ASSEMBLY R80



RO0401

Positions without LF code no.: upon request




Position	LF code no.	Description
1	1090916	DOSER RH
1	1090917	DOSER LH
2	1439822	DOSER LID
3	3240123	MICROSWITCH 16A 250V
4	1252046	MICROSWITCH BOX
5	1120201	SILICONE MEMBRANE
6	1252047	CHROME-PLATED DISPENSER RING
7	1252589	DOSER CYLINDER
8	1250933	SHAPED SPRING
10	1343031	UPPER STAR
11	1252587	CLOSING SECTOR RH
12	1343032	MIDDLE STAR
13	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
14	1186395	WASHER 8x18 mm
15	1343033	LOWER STAR
16	1250932	COFFEE TAMPER SPRING
18	1252588	COUNTER FOR COFFEE GRINDER
19	1250935	CONTACTOR SPRING RH
19	1250936	CONTACTOR SPRING LH
21	1252591	PAWL FOR COFFEE GRINDER/DOSER
22	1324921	DOSER PIN
26	1250937	SHAPED PIN SPRING
27	1250058	TRIGGERING SPRING
29	1225911	DOSER LEVER RH
29	1225912	LH DOSER LEVER WITH PIN
31	1250934	PIN SPRING
32	1385538	COFFEE TAMPER
33	1385001	MOBILE TAMPER COMPLETE
34	1241911	COFFEE TAMPER HANDLE
35	1324932	PIN FOR MANUAL COFFEE TAMPER
36	1250932	COFFEE TAMPER SPRING
37	1385536	COFFEE TAMPER SUPPORT
38	1385537	COFFEE TAMPER
39	1252581	COFFEE HOPPER LID ø 180 mm
40	1080917	COMPLETE COFFEE HOPPER
41	1252583	ADJUSTMENT RING NUT
42	1251916	GRINDING BURRS UPPER HOLDER
43	1324935	RR-45S/CC-45 HOPPER ADAPTER PIN
44	1250931	CONTROL PIN SPRING
46	1186921	GASKET FOR COFFEE OUTLET OPENING
47	1319160	THREE-POLE LEVER SWITCH 10A 400V
49	1252582	FILTER HOLDER FORK
51	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
52	1251917	GRINDING BURRS LOWER HOLDER
55	3068019	CAPACITOR µF 12,5 450V 50/60Hz
56	1351008	POWER RELAY 60.33
56	3351007	MINI RELAY 55.32 10A 240V 50/60Hz
58	1252585	COFFEE GRINDER/DOSER BASE
59	1313908	FOOT FOR COFFEE GRINDER/DOSER
60	1240406	MAGNETIC MICROSWITCH



GRINDER ASSEMBLY MC

MC



RO0501




Position	LF code no.	Description
2	1252581	COFFEE HOPPER LID ø 180 mm
8	1252584	COFFEE HOPPER CLOSING SHEET
10	1080917	COMPLETE COFFEE HOPPER
11	1252350	ADJUSTMENT RING NUT
12	1250121	CLUTCH SPRING
13	1252354	HOPPER SOCKET UNION
17	1251076	CONICAL GRINDING BURRS ROSSI (PAIR) RH
20	1186649	COFFEE OUTLET GASKET
22	3319019	RED BIPOLAR SWITCH 16A 250V
22	3319934	ORANGE BIPOLAR SWITCH 16A 250V
23	1252050	FILTER HOLDER FORK
36	1212010	REDUCTION GEAR FOR CAFFEE GRINDER
41	1212011	PLANETARY GEAR
46	3063005	BEARING 6202 2RS
55	1252045	COFFEE COLLECTING TRAY
57	1351005	KLIXON 2CR4-143
59	3351007	MINI RELAY 55.32 10A 240V 50/60Hz
60	3068019	CAPACITOR µF 12,5 450V 50/60Hz
64	1009005	ADHESIVE PLATE
65	1050001	SPIRAL CABLE
66	1390004	MAGNETIC MICROSWITCH ø 7x35 mm
67	1439822	DOSER LID
68	3240123	MICROSWITCH 16A 250V
69	1120201	SILICONE MEMBRANE
70	1240932	MICROSWITCH PUSH-BUTTON
71	1252046	MICROSWITCH BOX
72	1252047	CHROME-PLATED DISPENSER RING
73	1252589	DOSER CYLINDER
74	1241916	CONTROL KNOB
75	1250933	SHAPED SPRING
76	1324933	SPRING SHAFT SEAT
77	1343031	UPPER STAR
78	1252587	CLOSING SECTOR RH
79	1343032	MIDDLE STAR
80	1250932	COFFEE TAMPER SPRING
82	1343033	LOWER STAR
85	1252590	PIN GUIDE
86	1385539	COFFEE TAMPER ASSEMBLY ø 55 mm
87	1250935	CONTACTOR SPRING RH
88	1252588	COUNTER FOR COFFEE GRINDER
89	1252591	PAWL FOR COFFEE GRINDER/DOSER
90	1225911	DOSER LEVER RH
90	1225912	LH DOSER LEVER WITH PIN
92	1250937	SHAPED PIN SPRING
94	1324934	PIN ø 4x16 mm
95	1250934	PIN SPRING
97	1252591	PAWL FOR COFFEE GRINDER/DOSER
98	1250058	TRIGGERING SPRING
101	1324921	DOSER PIN
105	1439823	DOSER BOTTOM LID
107	1252355	COUNTER FOR COFFEE GRINDER
108	1250122	STROKE COUNTER SPRING
109	1252356	BOTTOM PAWL
110	1252357	DOSER BOTTOM LID
115	1225913	CHROME-PLATED RH/LH DOSER LEVER
116	1250123	DOSER LEVER RETURN SPRING
117	1252358	BUMPER FOR DOSER LEVER
118	1252359	PAWL PIN
119	1250124	PAWL PIN SPRING



GRINDER ASSEMBLY FM

FM



RO0601



ROSSI




Position	LF code no.	Description
2	1080046	COFFEE HOPPER 300 gr
5	1251050	CONICAL GRINDING BURRS ROSSI (PAIR) RH
21	1343029	COMPLETE DISPENSER BASE



GRINDER ASSEMBLY MAC64

MAC64



RO0701

Positions without LF code no.: upon request



Position	LF code no.	Description
1	1090011	DOSER LID ø 125 mm
2	1240045	LID FOR MICROSWITCH CASE
3	1240047	MICROSWITCH 0.1A 250V
4	1240046	MICROSWITCH SUPPORT
8	1240048	MICROSWITCH FLAP
11	1090010	DOSER CYLINDER ø 122x94 mm
12	1250149	SHAPED SPRING
13	1343059	SPRING HOLDER ROD ø 4x76 mm
15	1343058	TOP STAR
16	1343055	DOSING SHEET
17	1343057	MIDDLE STAR
18	1250148	SHAPED SPRING FOR STAR ø 15x54 mm
19	1343056	BOTTOM STAR
20	1252590	PIN GUIDE
22	1241078	DOSE ADJUSTMENT KNOB
26	1528631	CROSS HEAD SCREW M4x8 UNI 7687
29	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
32	1385539	COFFEE TAMPER ASSEMBLY ø 55 mm
37	1250122	STROKE COUNTER SPRING
38	1252355	COUNTER FOR COFFEE GRINDER
39	1324934	PIN ø 4x16 mm
40	1250934	PIN SPRING
44	1240044	MICROSWITCH 0.1A 250V
46	1252357	DOSER BOTTOM LID
49	1250124	PAWL PIN SPRING
50	1252416	PIN FOR PAWL ø 4x14 mm
51	1252591	PAWL FOR COFFEE GRINDER/DOSER
52	1252358	BUMPER FOR DOSER LEVER
53	1250123	DOSER LEVER RETURN SPRING
54	1225027	DOSER LEVER
56	1252413	6-TEETH PAWL
63	1252581	COFFEE HOPPER LID ø 180 mm
64	1080067	COFFEE HOPPER
65	1252584	COFFEE HOPPER CLOSING SHEET
70	1252048	NONTOXIC CLAMP
83	1252415	GRINDING ADJUSTMENT SCREW
85	1252414	ADJUSTMENT RING ROD
87	1241077	GRINDING ADJUSTMENT KNOB
96	1186694	GASKET FOR COFFEE OUTLET OPENING
97	1319214	BLACK BIPOLAR SWITCH 16A 250V
105	3351007	MINI RELAY 55.32 10A 240V 50/60Hz
111	3319019	RED BIPOLAR SWITCH 16A 250V
112	1251089	GRINDING BURRS TOP HOLDER ø 64 mm
113	1251090	GR.BURRS ROSSI-BRASILIA(PAIR)TITANIUM LH
113	1251094	GRINDING BURRS PAIR ROSSI LH
115	1528631	CROSS HEAD SCREW M4x8 UNI 7687
117	1251917	GRINDING BURRS LOWER HOLDER
118	1252378	THREADED RING NUT 15MCx1
119	1250130	SEEGER ø 35 mm
120	1252377	BEARING LOCKING WASHER
121	1252376	COMPENSATION RING
122	3063005	BEARING 6202 2RS
129	3063005	BEARING 6202 2RS
133	3068024	CAPACITOR µF 16 450V 50/60Hz
141	1528631	CROSS HEAD SCREW M4x8 UNI 7687
146	1252412	COFFEE COLLECTING TRAY
151	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689



Suitable for:

ROSSI



Adhesives

1009005 ADHESIVE PLATE



ROSSI 3299

Bearings

3063005 BEARING 6202 2RS

for ZANUSSI LS4-LS50-LS500
for ZANUSSI DRYER T1000-TT600-D1000V
for FAMA KNEADER KG5-KG8
for LA MINERVA VEGET.CHOPPER C/ETV-C/ETVS
for IGF PIZZA STRETCHER L30-L40-B30-B40
for GAM CUTTER PRATIC 3
for AGA DRYER E12-E18



ROSSI M2510

ROSSI 2510

ROSSI 2524

Bodies

1252585 COFFEE GRINDER/DOSER BASE



ROSSI 2730

Coffee tampers

1385537 COFFEE TAMPER



ROSSI 2632

1385538 COFFEE TAMPER

for BRASILIA RR45-R80-MAC64
for ROSSI RR45-RR55OD-R80



ROSSI 2673

ROSSI M2673

Suitable for:

1385539 COFFEE TAMPER ASSEMBLY ø 55 mm



ROSSI KIT.RIC.PF+...

ROSSI KIT.RIC.PF

ROSSI 2744+2745

ROSSI 2744+2745+6272+..

1241911

COFFEE TAMPER HANDLE



ROSSI 2636

1385536 COFFEE TAMPER SUPPORT



ROSSI 2782+1760

ROSSI 2782

1385001

MOBILE TAMPER COMPLETE



ROSSI S00030001

1324932 PIN FOR MANUAL COFFEE TAMPER



ROSSI 3910

Drawers

1080067 COFFEE HOPPER

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 2737.20

1252584

COFFEE HOPPER CLOSING SHEET



ROSSI 3352.10

1252581 COFFEE HOPPER LID ø 180 mm

for BRASILIA RR45-RR55-RR65-R80-MC-MAC64
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-R80-MC-MAC64



ROSSI 2738

1080046

COFFEE HOPPER 300 gr

for BRASILIA FM
for ROSSI FM



ROSSI M2864



Suitable for:

1080917 COMPLETE COFFEE HOPPER

for BRASILIA RR45-RR55-RR65-R80-MC
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-R65-R80-MC



ROSSI 2737.500.1

1080501 STANDARD COFFEE HOPPER 2 Kg

for BRASILIA RR55-RR65-CC45
for ROSSI RR55-RR65-CC45
for CUNILL MARFIL-COLOMBIA OLD MODELS
for FUTURMAT FP-FM



ROSSI 2675.50.1

Electronic printed-circuit boards

1390003 RELAY BOARD

for BRASILIA RR45-RR55-RR65-CC45
for ROSSI RR45-RR55-RR65-CC45



ROSSI SE01160091

Feet

1313908 FOOT FOR COFFEE GRINDER/DOSER

ROSSI 2740

Forks

1252044 FILTER HOLDER FORK

for BRASILIA RR55-RR65
for ROSSI RR55-RR65



ROSSI M2967

1252050 FILTER HOLDER FORK

for BRASILIA CC45-MC
for ROSSI CC45-MC



ROSSI M2846

Suitable for:

1252582 FILTER HOLDER FORK

for BRASILIA RR45-R80
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-R80



ROSSI 2722

Gaskets and seals

1252358 BUMPER FOR DOSER LEVER



ROSSI 3395.10

1186649 COFFEE OUTLET GASKET

for BRASILIA MC
for ROSSI MC



ROSSI M2838

1186497 GASKET FOR COFFEE OUTLET OPENING

for BRASILIA RR55-RR65
for ROSSI RR55-RR65



ROSSI M2919

1186694 GASKET FOR COFFEE OUTLET OPENING

for BRASILIA MAC64
for ROSSI MAC64



ROSSI 6427

1186921 GASKET FOR COFFEE OUTLET OPENING

for BRASILIA RR45-R80
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-R80



ROSSI 2766.10

1252048 NONTOXIC CLAMP



ROSSI M2923

Gears

1212011 PLANETARY GEAR

for BRASILIA MC
for ROSSI MC



ROSSI S5591

1212010 REDUCTION GEAR FOR CAFFEE GRINDER

for BRASILIA MC
for ROSSI MC



ROSSI 2800



Suitable for:

ROSSI



Grinders

1252350 ADJUSTMENT RING NUT

for BRASILIA MC
for ROSSI MC



ROSSI S2820.10

ROSSI S2820

1252580 ADJUSTMENT RING NUT

for BRASILIA RR45
for NUOVA SIMONELLI MDSA
for ROSSI RR45-RR55OD



ROSSI S2837

ROSSI 2837

ROSSI 2837.10

1252583 ADJUSTMENT RING NUT

for BRASILIA RR55-RR65-R80-CC45
for NUOVA SIMONELLI MDS
for ROSSI RR55-RR65-R80-CC45



ROSSI 2720

1251050 CONICAL GRINDING BURRS ROSSI (PAIR) RH

external ϕ 38/30 mm - internal ϕ 26/7 mm
thickness 17 mm
for BRASILIA FM
for ROSSI FM



ROSSI 5200

1251076 CONICAL GRINDING BURRS ROSSI (PAIR) RH

external ϕ 68/49 mm - internal ϕ 45/13 mm
thickness 25 mm - 4 mounting holes
inner groove for feather
for BRASILIA MC
for ROSSI MC
for CASADIO GC98



ROSSI M5585

ROSSI 5585

1251090 GR.BURRS ROSSI-BRASILIA(PAIR)TITANIUM LH

external ϕ 63.5 mm - internal ϕ 38 mm
thickness 9 mm - 3 mounting holes
for BRASILIA MOVIDA
for BRASILIA MAC64
for BRASILIA SUPERAUTOMATICA PLAZA-SECS
for ROSSI MAC64



ROSSI 4433.200

1251011 GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT

external ϕ 64 mm - internal ϕ 38 mm
thickness 9 mm - 3 fixing holes
for BRASILIA RR45-RR55-RR65-R80-CC45
for BRASILIA CENTURY NEW STYLE
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-R80-CC45
for FIAMMA RST MCF4-MCF7



ROSSI 4433

1251917 GRINDING BURRS LOWER HOLDER

for BRASILIA RR45-RR55-RR65-R80-CC45
for NEW SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-R80-CC45-MAC64



ROSSI S4984.30

ROSSI 4984

Suitable for:

1251094 GRINDING BURRS PAIR ROSSI LH

external ø 63.5 mm - internal ø 38 mm
thickness 9 mm - 3 mounting holes
for ROSSI MAC64
for BRASILIA MAC64



ROSSI 4433.64

1251089 GRINDING BURRS TOP HOLDER ø 64 mm

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 4899.64

1251916 GRINDING BURRS UPPER HOLDER

for BRASILIA RR45-RR55-RR65-R80-CC45
for NEW SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-R80-CC45



ROSSI 4899.1

ROSSI 4899.10

1252354 HOPPER SOCKET UNION

for BRASILIA MC
for ROSSI MC



ROSSI S5662

1252378 THREADED RING NUT 15MCx1

for BRASILIA MAC64
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55OD-MAC64



ROSSI 4983

Ironmongery (screws-nuts-washers-etc.)

1252414 ADJUSTMENT RING ROD



ROSSI 3558

1252377 BEARING LOCKING WASHER

for COFFEE GRINDER RR45



ROSSI 4328.1

1252376 COMPENSATION RING

for COFFEE GRINDER RR45



ROSSI 1634

1528631 CROSS HEAD SCREW M4x8 UNI 7687



ROSSI 1256



Suitable for:

1528501 S/STEEL CROSS SCREW M5x12 mm UNI 7689



ROSSI 1224.10

1184012

S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931



ROSSI 1041

1528627 S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933



ROSSI 1218.10

1186395

WASHER 8x18 mm



ROSSI

Knobs

1241916 CONTROL KNOB



ROSSI 3907.10

1241078

DOSE ADJUSTMENT KNOB



ROSSI 6265

1241077 GRINDING ADJUSTMENT KNOB



ROSSI 2861

Levers

1252356 BOTTOM PAWL



ROSSI 2639

1225913

CHROME-PLATED RH/LH DOSER LEVER

for BRASILIA MC

for ROSSI MC



ROSSI S7400.30

ROSSI S7400

Suitable for:

1252355 COUNTER FOR COFFEE GRINDER

for BRASILIA MC-MAC64
for ROSSI MC-MAC64



ROSSI 3374

1252588 COUNTER FOR COFFEE GRINDER

for BRASILIA RR45-RR55-RR65-R80-CC45-MC
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-CC45-R80-MC



ROSSI 3314

1225027 DOSER LEVER

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 6266

1225911 DOSER LEVER RH

for BRASILIA RR45-RR55-RR65-R80-CC45-MC
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-R80-CC45-MC



ROSSI 3909

1225912 LH DOSER LEVER WITH PIN

for BRASILIA RR45-R80-MC
for ROSSI RR45-RR55-RR65-R80-MC



ROSSI 5263

1252591 PAWL FOR COFFEE GRINDER/DOSER



ROSSI 2633.1

1252413 6-TEETH PAWL



ROSSI 6262

Microswitches

1240045 LID FOR MICROSWITCH CASE

for BRASILIA MAC64
for ROSSI MAC64



ROSSI 6259

1240406 MAGNETIC MICROSWITCH

for BRASILIA R80
for ROSSI R80



ROSSI



Suitable for:

1390004 **MAGNETIC MICROSWITCH** $\varnothing$ 7x35 mm



ROSSI 3154.10

1252046 **MICROSWITCH BOX**



ROSSI 2747

1240048 **MICROSWITCH FLAP**

for BRASILIA MAC64
for ROSSI MAC64



ROSSI 6257

1240932 **MICROSWITCH PUSH-BUTTON**



ROSSI 2753

1240046 **MICROSWITCH SUPPORT**

for BRASILIA MAC64
for ROSSI RR550D-MAC64



1240044 **MICROSWITCH 0.1A 250V**

for BRASILIA MAC64
for ROSSI MAC64



ROSSI 6258

1240047 **MICROSWITCH 0.1A 250V**

for BRASILIA MAC64
for ROSSI MAC64



ROSSI 3009

ROSSI 3009.10

3240123 **MICROSWITCH 16A 250V**

for ROBOT COUPE MIXER MP550A-MP600A
for PRIMUS WASHING MACHINE P6-P7
for PRIMUS DRYER T9-T11-T13-T16-T24-T35
for POLIMATIC WASHING MACHINE P65-P75
for POLIMATIC DRYER T9-T11-T13-T16-T24-T35
for GIRBAU WASHING MACHINE HS2007-HS2012-HS4007
HS4012-HS4022-HS4110
for GRANDIMPIANTI WASHING MACHINE WFM22
for SAEKO 3P-5P-8P-FS400-CRISTALLO600
for NECTA VENDING ASTRO-ASTROP-BRIO250-BRIO3-BRIO6
CAPRI-COILIBRI-FIRENZE-HYPERION-KIKKO-KIKKOMAX
KIKKORY-OBLO-ROMA-SILVER3-SILVER7-SPAZIO-VENEZIA
ZENITH
for MORETTI OVEN M90C-M130C



ROSSI 3202

Motors

1050001 SPIRAL CABLE



ROSSI 3085.10

Pins

1252415 GRINDING ADJUSTMENT SCREW

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 3549

1324931 INLET CONTROL PIN



ROSSI 2836

1252359 PAWL PIN



ROSSI 2690

1324934 PIN $\varnothing$ 4x16 mm



ROSSI 4296

1252416 PIN FOR PAWL $\varnothing$ 4x14 mm



ROSSI 6263

1324935 RR-45S/CC-45 HOPPER ADAPTER PIN



ROSSI 2635

Relays


1351005 KLIXON 2CR4-143



ROSSI M3247

3351007 MINI RELAY 55.32 10A 240V 50/60Hz

2 switching contacts



ROSSI 3068.10



Suitable for:

1351008 POWER RELAY 60.33

for BRASILIA R80
for ROSSI R80



ROSSI 3068

Rinse aid pumps and accessories

1252047 CHROME-PLATED DISPENSER RING



ROSSI 3333

1343029 COMPLETE DISPENSER BASE

for BRASILIA FM
for ROSSI FM



ROSSI 5297

1252357 DOSER BOTTOM LID

for BRASILIA MC-MAC64
for ROSSI MC-MAC64



ROSSI 7402

1439823 DOSER BOTTOM LID

for BRASILIA RR45-MC
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-MC



ROSSI M2631

ROSSI 2631

1252589 DOSER CYLINDER

for BRASILIA RR45-RR55-RR65-R80-CC45-MC
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-R80-MC



ROSSI 2652

1090010 DOSER CYLINDER ø 122x94 mm

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 6256

1090917 DOSER LH



ROSSI S7408.10

ROSSI 3895

1439822 DOSER LID

for BRASILIA RR45-RR55-RR65-R80-CC45-MC
for NUOVA SIMONELLI MDS-MDSA
for ROSSI RR45-RR55-RR65-R80-CC45-MC



ROSSI 2746.10

ROSSI 2746.20

ROSSI 2756.20

Suitable for:

1090011 DOSER LID ø 125 mm
for ROSSI MAC64
for BRASILIA MAC64



ROSSI 6255

1324921 DOSER PIN



ROSSI 5283.10

1090916 DOSER RH



ROSSI S7408.20

ROSSI 7408.20

1120201 SILICONE MEMBRANE



ROSSI 2733

1343059 SPRING HOLDER ROD ø 4x76 mm



ROSSI 6264

1324933 SPRING SHAFT SEAT



ROSSI 5248


Springs

1250121 CLUTCH SPRING



ROSSI M2008.1

1250932 COFFEE TAMPER SPRING



ROSSI 2029

1250936 CONTACTOR SPRING LH



ROSSI 2136

1250935 CONTACTOR SPRING RH



ROSSI 2014

1250931 CONTROL PIN SPRING



ROSSI 2018

1250123 DOSER LEVER RETURN SPRING
for BRASILIA MC-MAC64
for ROSSI MC-MAC64



ROSSI 2049



Suitable for:

1250124 PAWL PIN SPRING

1250934 PIN SPRING



ROSSI 2066

1250130 SEEGER $\varnothing$ 35 mm
for COFFEE GRINDER RR45

ROSSI 2019

1250937 SHAPED PIN SPRING



ROSSI 1640

1250149 SHAPED SPRING
for BRASILIA MAC64
for ROSSI MAC64

ROSSI 2020

1250933 SHAPED SPRING



ROSSI 2017.20

1250148 SHAPED SPRING FOR STAR $\varnothing$ 15x54 mm

ROSSI 2017

1250122 STROKE COUNTER SPRING



ROSSI 2075

1250058 TRIGGERING SPRING

ROSSI 2037



ROSSI 2001.10

Stars and spare parts

1343056 BOTTOM STAR

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 6252

1252587 CLOSING SECTOR RH



ROSSI 3321

1343055 DOSING SHEET



ROSSI 6254

1343033 LOWER STAR



ROSSI 2729

1343032 MIDDLE STAR



ROSSI 2728

1343057 MIDDLE STAR

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 6251

1252590 PIN GUIDE



ROSSI 2726

1343058 TOP STAR

for ROSSI MAC64
for BRASILIA MAC64



ROSSI 6250

1343031 UPPER STAR



ROSSI 2727



Suitable for:

ROSSI



Starting capacitors

3068019 CAPACITOR μ F 12,5 450V 50/60Hz

operating temperature -25+85°C

in compliance with EEC 93/68 and 92/31 regulations



ROSSI 3177

3068024 CAPACITOR μ F 16 450V 50/60Hz

operating temperature -25+85°C

in compliance with EEC 93/68 and 92/31 regulations



ROSSI 3251

Switches

1319214 BLACK BIPOLAR SWITCH 16A 250V

"START" silk-screen printing

mounting hole 30x22 mm

for ROSSI MAC64

for BRASILIA MAC64



ROSSI 6413

3319934 ORANGE BIPOLAR SWITCH 16A 250V

with indicator lamp

0-1 silk-screen printing

max temperature 120°C

mounting hole 22x30 mm



ROSSI 3253

3319019 RED BIPOLAR SWITCH 16A 250V

with indicator lamp

max temperature 120°C

mounting hole 22x30 mm



ROSSI 3253

1319160 THREE-POLE LEVER SWITCH 10A 400V

for BRASILIA R80

for ROSSI R80

for CASADIO MOKABIX-G84-GC98



ROSSI 3170.10

Trays

1252045 COFFEE COLLECTING TRAY

for BRASILIA CC45-MC

for ROSSI CC45-MC



ROSSI 2642.10

1252412 COFFEE COLLECTING TRAY

for ROSSI MAC64

for BRASILIA MAC64



ROSSI 6411



Suitable for:

1252586 COFFEE COLLECTION TRAY

for BRASILIA RR45

for NUOVA SIMONELLI MDS-MDSA

for ROSSI RR45



ROSSI 2840

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA

via Voltri, 80 – 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 – Fax +39 0547 34 11 10
www.lfricambi724.it – www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 – Fax: +39 0547 34 11 55
www.lfspareparts724.com – www.lfspareparts724.mobi
export@lfspareparts.com

FRANCE



EPGC

13, Rue des Forts - 59960 Neuville-en-Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
epgc@epgc.com

DEUTSCHLAND



LF GmbH

Junkersstrasse, 1 – D-82178 Puchheim – München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro

Sennweidstrasse, 45 – CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF oficina de venta

Calle Ciudad real, 10 – 45517 Escalonilla – Toledo
Tlf. +34 925 75 83 23
Fax +34 925 75 82 09
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

ESPAÑA



DAGA Accesorios S.L.

Calle Ciudad Real, 10 – 45517 Escalonilla – Toledo
Tlf. +34 914 77 91 00
Fax +34 914 77 90 81
www.dagarepuestos724.es
comercial@dagarepuestos.es

RUSSIA



OOO LF

ul, Anatoliya Zhivova, 8 – office 1 – 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspareparts.ru

CHINA



LF China

Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. – 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspareparts.com