



Spare parts for:
Coffee grinders



Suitable for:

BRASILIA




This catalogue is automatically generated.
Therefore, the sequence of the items might
not be always shown at best.
Updates will be issued in case of additions
and/or amendments.
Suitable universal spare parts may not be included





GRINDER ASSEMBLY RR45



BFMC01

Positions without LF code no.: upon request




BRASILIA



Position	LF code no.	Description
13	1252582	FILTER HOLDER FORK
14	1528631	CROSS HEAD SCREW M4x8 UNI 7687
15	1390003	RELAY BOARD
17	3068019	CAPACITOR μ F 12.5 450V 50/60Hz
29	3319019	RED BIPOLAR SWITCH 16A 250V
29	3319934	ORANGE BIPOLAR SWITCH 16A 250V
31	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
52	1324933	SPRING SHAFT SEAT
55	1252587	CLOSING SECTOR RH
60	1252590	PIN GUIDE
63	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
81	3240123	MICROSWITCH 16A 250V
84	1252046	MICROSWITCH BOX
86	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
91	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
93	1252470	COUNTER FOR COFFEE GRINDER/DOSER
101	1241911	COFFEE TAMPER HANDLE
102	1324932	PIN FOR MANUAL COFFEE TAMPER



GRINDER ASSEMBLY RR55-RR65



BFMC02

Positions without LF code no.: upon request



BRASILIA




Position	LF code no.	Description
5	3240123	MICROSWITCH 16A 250V
6	1252046	MICROSWITCH BOX
8	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
12	1324933	SPRING SHAFT SEAT
15	1252587	CLOSING SECTOR RH
19	1252590	PIN GUIDE
23	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
42	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
44	1252470	COUNTER FOR COFFEE GRINDER/DOSER
65	1252583	ADJUSTMENT RING NUT
70	1186497	GASKET FOR COFFEE OUTLET OPENING
72	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
75	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
78	1528631	CROSS HEAD SCREW M4x8 UNI 7687
86	3068019	CAPACITOR μ F 12.5 450V 50/60Hz
96	1390003	RELAY BOARD
103	3319019	RED BIPOLAR SWITCH 16A 250V
103	3319934	ORANGE BIPOLAR SWITCH 16A 250V



GRINDER ASSEMBLY R80

R80



BFMC03

Positions without LF code no.: upon request



BRASILIA





Position	LF code no.	Description
3	3240123	MICROSWITCH 16A 250V
4	1252046	MICROSWITCH BOX
11	1252587	CLOSING SECTOR RH
13	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
18	1252470	COUNTER FOR COFFEE GRINDER/DOSER
34	1241911	COFFEE TAMPER HANDLE
35	1324932	PIN FOR MANUAL COFFEE TAMPER
41	1252583	ADJUSTMENT RING NUT
47	1319160	THREE-POLE LEVER SWITCH 10A 400V
49	1252582	FILTER HOLDER FORK
51	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
55	3068019	CAPACITOR μ F 12.5 450V 50/60Hz
56	1351008	POWER RELAY 60.33
56	3351007	MINI RELAY 55.32 10A 240V 50/60Hz



GRINDER ASSEMBLY CC45

CC45



BFMC04



BRASILIA




Position	LF code no.	Description
11	1252583	ADJUSTMENT RING NUT
15	3319019	RED BIPOLAR SWITCH 16A 250V
15	3319934	ORANGE BIPOLAR SWITCH 16A 250V
22	1252050	FILTER HOLDER FORK
25	1251011	GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
28	1528631	CROSS HEAD SCREW M4x8 UNI 7687
48	3068019	CAPACITOR μ F 12.5 450V 50/60Hz
50	1390003	RELAY BOARD
54	3240123	MICROSWITCH 16A 250V
56	1252046	MICROSWITCH BOX
60	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689
64	1324933	SPRING SHAFT SEAT
67	1252587	CLOSING SECTOR RH
74	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
76	1252590	PIN GUIDE
80	1184012	S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931
93	1252470	COUNTER FOR COFFEE GRINDER/DOSER



GRINDER ASSEMBLY MC

MC



BFMC05



BRASILIA




Position	LF code no.	Description
11	1252350	ADJUSTMENT RING NUT
13	1252354	HOPPER SOCKET UNION
17	1251076	CONICAL GRINDING BURRS ROSSI (PAIR) RH
20	1186649	COFFEE OUTLET GASKET
22	3319019	RED BIPOLAR SWITCH 16A 250V
22	3319934	ORANGE BIPOLAR SWITCH 16A 250V
23	1252050	FILTER HOLDER FORK
36	1212010	REDUCTION GEAR FOR CAFFEE GRINDER
41	1212011	PLANETARY GEAR
46	3063005	BEARING 6202 2RS
59	3351007	MINI RELAY 55.32 10A 240V 50/60Hz
60	3068019	CAPACITOR μ F 12.5 450V 50/60Hz
68	3240123	MICROSWITCH 16A 250V
71	1252046	MICROSWITCH BOX
76	1324933	SPRING SHAFT SEAT
78	1252587	CLOSING SECTOR RH
85	1252590	PIN GUIDE
88	1252470	COUNTER FOR COFFEE GRINDER/DOSER
110	1252357	DOSER BOTTOM LID
116	1250123	DOSER LEVER RETURN SPRING
118	1252359	PAWL PIN



GRINDER ASSEMBLY FM

FM





BRASILIA




Position	LF code no.	Description
5	1251050	CONICAL GRINDING BURRS ROSSI (PAIR) RH



GRINDER ASSEMBLY MAC64

MAC64





BRASILIA



Position	LF code no.	Description
3	1240047	MICROSWITCH 0.1A 250V
11	1090010	DOSER CYLINDER ø 122x94 mm
13	1343059	SPRING HOLDER ROD ø 4x76 mm
15	1343058	TOP STAR
16	1343055	DOSING SHEET
17	1343057	MIDDLE STAR
18	1250148	SHAPED SPRING FOR STAR ø 15x54 mm
20	1252590	PIN GUIDE
26	1528631	CROSS HEAD SCREW M4x8 UNI 7687
29	1528627	S/STEEL SCREW T.S.P.C.E.I.M8x20 UNI 5933
39	1252416	PIN FOR PAWL ø 4x14 mm
44	1240044	MICROSWITCH 0.1A 250V
46	1252357	DOSER BOTTOM LID
50	1252413	6-TEETH PAWL
53	1250123	DOSER LEVER RETURN SPRING
83	1252415	GRINDING ADJUSTMENT SCREW
85	1252414	ADJUSTMENT RING ROD
96	1186694	GASKET FOR COFFEE OUTLET OPENING
105	3351007	MINI RELAY 55.32 10A 240V 50/60Hz
111	3319019	RED BIPOLAR SWITCH 16A 250V
113	1251090	GR.BURRS ROSSI-BRASILIA(PAIR)TITANIUM LH
113	1251094	GRINDING BURRS PAIR ROSSI LH
115	1528631	CROSS HEAD SCREW M4x8 UNI 7687
118	1252378	THREADED RING NUT 15MCx1
119	1250130	SEEGER ø 35 mm
120	1252377	BEARING LOCKING WASHER
121	1252376	COMPENSATION RING
122	3063005	BEARING 6202 2RS
133	3068024	CAPACITOR µF 16 450V 50/60Hz
141	1528631	CROSS HEAD SCREW M4x8 UNI 7687
146	1252412	COFFEE COLLECTING TRAY
151	1528501	S/STEEL CROSS SCREW M5x12 mm UNI 7689



Suitable for:

BRASILIA



Suitable for:

Adjustment rings for coffee grinder

- 1252350 ADJUSTMENT RING NUT**
for Grinder-dispenser (BRASILIA) MC
for Grinder-dispenser (ROSSI) MC



BRASILIA 13912.0.00.02

Bearings

- 3063005 BEARING 6202 2RS**
external \varnothing 35 mm -internal \varnothing 15 mm-thickness 11 mm



BRASILIA 05507.0.00.03

BRASILIA 11756.0.00.04

Capacitors

- 3068019 CAPACITOR μ F 12.5 450V 50/60Hz**
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



BRASILIA 00602.0.00.08

BRASILIA 01897.2.00.08

- 3068024 CAPACITOR μ F 16 450V 50/60Hz**
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



BRASILIA 09406.2.00.08

- 3068027 CAPACITOR μ F 20 450V 50/60Hz**
operating temperature $-25+85^{\circ}\text{C}$
in compliance with EEC 93/68 and 92/31 regulations



BRASILIA 09405.2.00.08

Circlips

1250130 SEEGER \varnothing 35 mm
for Grinder-dispenser (ROSSI) RR45



BRASILIA 05504.0.00.03

Clamps

1168011 STAINLESS STEEL CLAMP FOR FLANGE PUMP



BRASILIA 02223.0.00.03

Coffee measuring spoons

1069001 PLASTIC MEASURING SPOON 20 ml



BRASILIA 00782.0.00.02

1069002 STAINLESS STEEL MEASURING SPOON 20 ml



BRASILIA

Containers for coffee

1080917 COFFEE HOPPER
for Grinder-dispenser (BRASILIA) MC - RR45 - RR55
RR65 - R80
for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA
for Grinder-dispenser (ROSSI) MC - RR45 - RR55
RR65 - R80



BRASILIA 01161.4.00.09

BRASILIA 12043.4.00.09

BRASILIA 12043.8.00.09



Suitable for:

BRASILIA



Suitable for:

Counters

1252470 COUNTER FOR COFFEE GRINDER/DOSER
for Grinder-dispenser (SAN MARCO) SMFK - SMMK
SM90 - SM91 - SM92 - SM95 - SM96



BRASILIA 01986.2.00.08

Dosers for coffee

1252357 DOSER BOTTOM LID
for Grinder-dispenser (BRASILIA) MAC64 - MC
for Grinder-dispenser (ROSSI) MAC64 - MC



BRASILIA 17176.0.00.02

1090010 DOSER CYLINDER ø 122x94 mm
for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (ROSSI) MAC64



BRASILIA 18077.0.00.02

1343059 SPRING HOLDER ROD ø 4x76 mm



BRASILIA 19966.0.00.04


1324933 SPRING SHAFT SEAT



BRASILIA 08612.0.00.04

Electronic printed-circuit boards

1390003 RELAY BOARD
for Grinder-dispenser (BRASILIA) CC45 - RR45
RR55 - RR65
for Grinder-dispenser (ROSSI) CC45 - RR45 - RR55
RR65



BRASILIA 11051.2.00.08

Feet

1313017 FOOT ø 20x15 mm



BRASILIA 01489.0.00.02



Forks for portafilter coffee grinder

1252050 FILTER HOLDER FORK
for Grinder-dispenser (BRASILIA) CC45 - MC
for Grinder-dispenser (ROSSI) CC45 - MC



BRASILIA 13914.0.00.02


1252582 FILTER HOLDER FORK
for Grinder-dispenser (BRASILIA) RR45 - R80
for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA
for Grinder-dispenser (ROSSI) RR45 - R80



BRASILIA 00798.0.00.02

Gaskets and seals

1186649 COFFEE OUTLET GASKET
for Grinder-dispenser (BRASILIA) MC
for Grinder-dispenser (ROSSI) MC




BRASILIA 13913.0.00.02

1186497 GASKET FOR COFFEE OUTLET OPENING
for Grinder-dispenser (BRASILIA) RR55 - RR65
for Grinder-dispenser (ROSSI) RR55 - RR65



BRASILIA 13918.0.00.02

1186694 GASKET FOR COFFEE OUTLET OPENING
for Grinder-dispenser (BRASILIA) MC
for Grinder-dispenser (ROSSI) MC



BRASILIA 19086.0.00.02

1186421 O-RING 02018 EPDM



BRASILIA 00831.0.00.02

BRASILIA 01428.0.00.02

1186223 O-RING 02056 EPDM



BRASILIA 01389.0.00.02

Gears

1212011 PLANETARY GEAR
for Grinder-dispenser (BRASILIA) MC
for Grinder-dispenser (ROSSI) MC



BRASILIA 13957.0.00.04

1212010 REDUCTION GEAR FOR CAFFEE GRINDER
for Grinder-dispenser (BRASILIA) MC
for Grinder-dispenser (ROSSI) MC



BRASILIA 11415.0.00.02



Suitable for:

BRASILIA

Suitable for:



Grinders

1251050 CONICAL GRINDING BURRS ROSSI (PAIR) RH
 external \varnothing 38/30 mm - internal \varnothing 26/7 mm
 thickness 17/20,3 mm
 for Grinder-dispenser (BRASILIA) FM
 for Grinder-dispenser (IBERITAL) MINIMOLINO
 for Grinder-dispenser (ROSSI) FM



BRASILIA 13659.3.00.04

1251076 CONICAL GRINDING BURRS ROSSI (PAIR) RH
 external \varnothing 68/49 mm - internal \varnothing 41/13 mm
 thickness 25 mm - 4 mounting holes
 inner groove for feather
 for Grinder-dispenser (BRASILIA) MC
 for Grinder-dispenser (CASADIO) GC98
 for Grinder-dispenser (MACAP) M7K - M7KA - M7KT
 for Grinder-dispenser (OBEL) MITOCONIC
 for Grinder-dispenser (ROSSI) MC



BRASILIA 03603.3.00.04

1251090 GR.BURRS ROSSI-BRASILIA(PAIR)TITANIUM LH
 external \varnothing 63.5 mm - internal \varnothing 38 mm
 thickness 9 mm - 3 mounting holes
 for Grinder-dispenser (BRASILIA) MAC64
 for Grinder-dispenser (ROSSI) MAC64



BRASILIA 10775.3.00.04

1251016 GRINDING BURRS (PAIR) ROSSI LEFT
 external \varnothing 50 mm - internal \varnothing 31 mm
 thickness 8.5 mm - 3 mounting holes
 for Grinder-dispenser (BRASILIA) BFD
 for Grinder-dispenser (ROSSI) BFD



BRASILIA 00059.3.00.04

1251011 GRINDING BURRS ASTRAL-ROSSI (PAIR) LEFT
 external \varnothing 64 mm - internal \varnothing 38 mm
 thickness 9 mm - 3 fixing holes
 for Grinder-dispenser (BRASILIA) CC45 - RR45
 RR55 - RR65 - R80
 for Grinder-dispenser (FIAMMA RST) MCF4 - MCF7
 for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA
 for Grinder-dispenser (ROSSI) CC45 - RR45 - RR55
 RR65 - R80



BRASILIA 00058.2.00.04

BRASILIA 00058.3.00.04

1251017 GRINDING BURRS BRASILIA (PAIR) LEFT
 external \varnothing 63 mm - internal \varnothing 37 mm
 thickness 9 mm - 3 fixing holes
 for Grinder-dispenser (BRASILIA) VIP



BRASILIA 05617.3.00.04

1251094 GRINDING BURRS PAIR ROSSI LH
 external \varnothing 63.5 mm - internal \varnothing 38 mm
 thickness 9 mm - 3 mounting holes
 for Grinder-dispenser (BRASILIA) MAC64
 for Grinder-dispenser (ROSSI) MAC64 - RR550D




BRASILIA 19164.3.00.04



Grinding burr holders

1252583 ADJUSTMENT RING NUT


for Grinder-dispenser (BRASILIA) CC45 - RR55
RR65 - R80
for Grinder-dispenser (NUOVA SIMONELLI) MDS
for Grinder-dispenser (ROSSI) CC45 - RR55 - RR65
R80



BRASILIA 00796.0.00.02

1252354 HOPPER SOCKET UNION

for Grinder-dispenser (BRASILIA) MC
for Grinder-dispenser (ROSSI) MC



BRASILIA 11505.0.00.01

1252378 THREADED RING NUT 15MCx1

for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (NUOVA SIMONELLI) MDS - MDSA
for Grinder-dispenser (ROSSI) MAC64 - RR45
RR550D



BRASILIA 05351.0.00.04

Ironmongery (screws,nuts,washers)

1252414 ADJUSTMENT RING ROD



BRASILIA 19968.0.00.04

1252377 BEARING LOCKING WASHER

for Grinder-dispenser (BRASILIA) RR45
for Grinder-dispenser (ROSSI) RR45



BRASILIA 05352.0.00.04

BRASILIA 19636.0.00.03

1348025 BRASS NUT M3



BRASILIA 01263.0.00.03

1252376 COMPENSATION RING

for Grinder-dispenser (BRASILIA) RR45
for Grinder-dispenser (ROSSI) RR45



BRASILIA 05506.0.00.03

BRASILIA 20093.0.00.03



Suitable for:

BRASILIA



1528631 CROSS HEAD SCREW M4x8 UNI 7687



BRASILIA 07079.0.00.03

BRASILIA 20096.0.00.03

Suitable for:

1528501 S/STEEL CROSS SCREW M5x12 mm UNI 7689



BRASILIA 01242.0.00.03

BRASILIA 12912.0.00.03

1184012 S/STEEL SCREW T.C.C.E.I. M5x10 UNI 5931



BRASILIA 01247.0.00.03

1528627 S/STEEL SCREW T.S.P.C.E.I. M8x20 UNI 5933



BRASILIA 01313.0.00.03

1528632 TAPERED END PIN M5x6 UNI 5927



BRASILIA 10945.0.00.03

Knobs

1241542 BLACK KNOB FOR CONVERTER
square hole 5x5 mm



BRASILIA

Microswitches

1252046 MICROSWITCH BOX



BRASILIA 01163.4.00.09

1240044 MICROSWITCH 0.1A 250V
for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (ROSSI) MAC64



BRASILIA 20035.2.00.08

Suitable for:

1240047 MICROSWITCH 0.1A 250V
for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (ROSSI) MAC64



BRASILIA 20033.2.00.08

Suitable for:


3240123 MICROSWITCH 16A 250V



BRASILIA 00751.2.00.08

Pawls for coffee grinder dosers


1252413 6-TEETH PAWL



BRASILIA 20100.0.00.03

Pins

1252415 GRINDING ADJUSTMENT SCREW
for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (ROSSI) MAC64



BRASILIA 19965.0.00.04

1252359 PAWL PIN



BRASILIA 18200.0.00.04

1252416 PIN FOR PAWL \varnothing 4x14 mm



BRASILIA 19690.0.00.04

Pull-through brushes

1384001 BRUSH FOR COFFEE SHOWER



BRASILIA 19523.0.00.02



Suitable for:


BRASILIA



Suitable for:


Relays

3351154 BASE OCTAL ES8 10A 400V
8 poles



BRASILIA 01810.2.00.08

3351007 MINI RELAY 55.32 10A 240V 50/60Hz
2 switching contacts
manual push-button
for PIZZA SHAPER PF45MTE



BRASILIA 01955.2.00.08

1351008 POWER RELAY 60.33
for Grinder-dispenser (BRASILIA) R80
for Grinder-dispenser (ROSSI) R80



BRASILIA 01955.2.00.08

Springs

1250123 DOSER LEVER RETURN SPRING
for BRASILIA MC-MAC64
for ROSSI MC-MAC64



BRASILIA

1250548 INFUSION SPRING \varnothing 11x58 mm



BRASILIA 03788.0.00.03

1250148 SHAPED SPRING FOR STAR \varnothing 15x54 mm



BRASILIA 20101.0.00.02

Stars and spare parts

1252587 CLOSING SECTOR RH



BRASILIA 01772.0.00.01


1343055 DOSING SHEET



BRASILIA 20061.0.10.01

Suitable for:

1343057 MIDDLE STAR
for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (ROSSI) MAC64



BRASILIA 20134.0.00.02

Suitable for:

1252590 PIN GUIDE



BRASILIA 08563.0.00.02

1343058 TOP STAR
for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (ROSSI) MAC64



BRASILIA 20135.0.00.02


Switches

3319294 BLACK BIPOLAR SWITCH 16A 250V
with red led indicator light
mounting hole 30x22 mm



BRASILIA 08474.2.00.08

1319464 ORANGE BIPOLAR SWITCH 16A 250V
with indicator lamp
mounting hole \varnothing 25 mm



BRASILIA 01975.2.00.08


BRASILIA 01976.2.00.08

3319934 ORANGE BIPOLAR SWITCH 16A 250V
with indicator lamp
0-1 silk-screen printing
max temperature 120°C
mounting hole 22x30 mm



BRASILIA 03632.2.00.08

3319019 RED BIPOLAR SWITCH 16A 250V
with indicator lamp
max temperature 120°C
mounting hole 22x30 mm



BRASILIA 03632.2.00.08

1319160 THREE-POLE LEVER SWITCH 10A 400V
for Grinder-dispenser (BRASILIA) R80
for Grinder-dispenser (CASADIO) GC98 - G84
MOKABIX
for Grinder-dispenser (ROSSI) R80



BRASILIA 00750.2.00.08



Suitable for:

BRASILIA



Suitable for:

Tampers for coffee

1385053 ANODISED ALUMINUM TAMPER \varnothing 58 mm
flat pressing area



BRASILIA

1385005 BALL ALUMINUM TAMPER \varnothing 57 mm



BRASILIA

1241911 COFFEE TAMPER HANDLE



BRASILIA 04357.0.00.02

1385002 NYLON COFFEE TAMPER \varnothing 50/57 mm



BRASILIA 00779.0.00.02

1324932 PIN FOR MANUAL COFFEE TAMPER



BRASILIA 04658.0.00.04

Trays

1252412 COFFEE COLLECTING TRAY
for Grinder-dispenser (BRASILIA) MAC64
for Grinder-dispenser (ROSSI) MAC64



BRASILIA 20062.0.40.01

BRASILIA 24566.2.41.01

The data herewith contained may change without notice and LF SpA cannot be held responsible for possible errors stated or resulting by the use of this document. All rights reserved. No part of this publication may be reproduced without written permission by LF SpA.



LF SpA
via Voltri, 80 - 47522 Cesena (FC) ITALIA
Tel. +39 0547 34 11 11 - Fax +39 0547 34 11 10
www.lfricambi724.it - www.lfricambi724.mobi
info@lfricambi.it
Export Dept.: Tel. +39 0547 34 11 50 - Fax: +39 0547 34 11 55
www.lfspareparts724.com - www.lfspareparts724.mobi
export@lfspaceparts.com

FRANCE



EPGC Sas
13, Rue des Forts - 59960 Neuville en Ferrain
Tél. +33 (0)3 20 25 06 21
Fax +33 (0)3 20 25 34 12
www.epgc.com
www.epgc724.mobi
epgc@epgc.com

DEUTSCHLAND



LF GmbH
Junkersstrasse, 1 - D-82178 Puchheim - München
Tel. +49 89 89 45 78 66
Fax +49 89 89 45 78 88
www.lfersatzteile724.de
www.lfersatzteile724.mobi
info@lfersatzteile.de

SCHWEIZ



LF GmbH Verkaufsbüro
Sennweidstrasse, 45 - CH-6312 Steinhausen
Tel. +41 (0)41 760 15 80-1
Fax +41 (0)41 760 15 85
www.lfersatzteile724.ch
www.lfersatzteile724.mobi
info@lfersatzteile.ch

ESPAÑA



LF Repuestos Horeca S.L.U.
Calle Ciudad Real, 10 - 45517 Escalonilla - Toledo
Tif. +34 91 477 91 00
Fax +34 91 477 90 81
www.lfrepuestos724.es
www.lfrepuestos724.mobi
info@lfrepuestos.es

UNITED KINGDOM



LF Spare Parts Ltd.
A10a Lakeside Business Park, Broadway Lane
South Cerney, Gloucestershire GL7 5XL
Tel. +44 (0)1285 86 16 25
Fax +44 (0)1285 86 39 49
www.lfspareparts724.co.uk
www.lfspareparts724.mobi
info@lfspaceparts.co.uk

RUSSIA



OOO LF
ul, Anatoliya Zhivova, 8 - office 1 - 123100 Moscow
Tel. +7 499 259 85 75
Fax +7 495 725 26 53
www.lfspareparts724.ru
www.lfspareparts724.mobi
info@lfspaceparts.ru

CHINA



LF China
Room 102, House 8, Lane 725, Mao Tai Rd.
Changning Dist. - 200336 Shanghai
Tel. +86 (0)21 33 53 66 31
Fax +86 (0)21 33 53 66 32
www.lfspareparts724.com
www.lfspareparts724.mobi
china@lfspaceparts.com